PARABOND PARQUET 540



CHARACTERISTICS

- 1-component parquet adhesive
- Ready-to-use
- Excellent stance (adhesive lines remain stable)
- · High end strength
- Powerful and permanently elastic: absorbs the working movement of parguet floors
- Fast strength build-up, so that the parquet can be walked on after only 8 hours
- · Better acoustic comfort
- Low odour
- Solvent, water, isocyanate and phthalate free

APPLICATIONS

- Bonding parquet floors, covering lifts with parquet, gluing parquet floors to old ceramic tiles...
- Suitable for solid parquet, multi-layer parquet, mosaic parquet, industrial parquet (slat on side/slat on edge), lamparquet, chipboards and OSB.
- Suitable for the most common types of wood and particularly suitable for problematic woods such as beech, maple and bamboo.
- · For both absorbent and non-absorbent surfaces.
- Suitable for applications where the parquet must be walked on quickly.
- Suitable for use on floors with underfloor heating and floor cooling (reversible system) (depending on the approval of the flooring manufacturer), if applied fully with a notched trowel.

TECHNICAL CHARACTERISTICS	
Type of product	Hybrid polymer
Density (g/ml)	1.63
Number of components	1
Shear strength (N/mm²)	2.1
Temperature resistance	-40°C - +70°C
Curing system	Curing by air humidity
Sandable after	8 - 24 h
Walkable after	8 h
Working time at 23 degrees C and 50% R.H.	30 minutes
Temperature product when applying	Minimum +15°C
Shore A hardness: ISO 868	50
Tensile strength: ISO 37 (N/mm²)	1.8
% Elongation at break: ISO 37	120
Dry matter content	±100%
Shelf life of unopened product	12 months
Storage conditions	Store in a dry, cool place at +5°C to +25°C. Keep out of direct sunlight.

PACKING AND COLOURS

bucket 15kg - 33 pieces/pallet

Beige

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



Last Update: 28-10-2025

METHOD OF USE

Preparation

- Use in well-ventilated rooms. Good ventilation is important during application and curing of the product.
- The user needs to make sure that the product is suitable for the application. Consult our technical service if necessary.
- Remove irregularities such as old adhesive residues mechanically
- Preferably roughen/sand smooth surfaces to increase the contact surface.
- Uneven floors should be levelled first using a levelling layer like DL Egaline of DL Maxi Egaline.
- Measure the moisture content of the substrate using a carbide meter in the core of the screed and compare it with the maximum value prescribed by the flooring manufacturer.
- Preferably let the parquet acclimatize for a few days in the original packaging in the relevant room.
- Check the moisture of the wood before installation and compare it with the value prescribed by the manufacturer. Installation is strongly discouraged below 7% or above 11% wood moisture.
- The surface should be permanently dry, clean and free from dust, paint, loose parts.... and must retain its pressure and form. Check whether surface complies with the applicable norms and technical regulations.
- Before installing on underfloor heating and cooling, it must be turned off for at least 48 hours after following the heating and cooling protocol to allow the screed to dry properly and to minimize the risk of cracking.
- Surfaces that are not sturdy or compact enough must be reinforced with Primer WB, Primer PU Turbo or Hydroblocker 2K.

Primers

• It is necessary to apply the Primer WB or Primer PU Turbo before use on highly absorbent surfaces.

Application

- The product should be applied directly to the substrate with a coarsely serrated adhesive trowel. The adhesive must be spread evenly over the entire surface.
- Please note the working time of the adhesive. Don't apply too much adhesive in one stroke.
- Slide the parquet into the wet adhesive on the substrate (perpendicular to the adhesive beads) and tap with a rubber hammer. The material can at this stage still be adjusted, just push it down well.
- The gap between the wall and the parquet must be at least 10-15 mm.
- If necessary, the parquet could be slightly loaded to ensure perfect spread of the adhesive. Many wood species should be tamped down from above. Parquet without tongue and groove should be rolled down using a cylinder roller.

Consumption

Consumption in full-surface bonding

- 700 900 g/m² with B3 serrated trowel Pre-manufactured parquet systems/planks, lamparquet, mosaic parquet
- 900 1200 g/m² with B11 serrated trowel Solid parquet, pre-manufactured laths/panels, industrial parquet, chip board, OSB
- For bonding long, wide planks and in case of bonding upon uneven supports, it may be necessary to use a trowel with coarse serration to prevent hollow areas in the adhesive base.

Cleaning

• Any adhesive seeping along the edges can be removed with a spatula. Uncured adhesive residues can be removed using Parasilico Cleaner, Multi-Purpose Super Cleaner or Cleaning Wipes

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



info@dl-chem.com - www.dl-chem.com

Last Update: 28-10-2025

- Tools, surfaces and uncured residues can be removed with Parasilico Cleaner, Multi-Purpose Super Cleaner or Cleaning Wipes. Remainder of silicone can be removed with Silicone Remover after curing
- After curing remove mechanically.

SAFETY

Consult the safety information on the packaging and the safety data sheet for more information.

POINTS OF ATTENTION

- Not suitable for permanent submersion.
- Not suitable for use on butiminous surfaces.
- Not suitable for use on PE, PP, PA, PTFE (Teflon).
- Avoid contact with plasticizer-containing materials such as bitumen, neoprene, EPDM, butyl... as these can lead to loss of adhesion or discoloration.
- Not suitable for application outside.
- As there is an extended range of parquet floors on the market, you have to make sure that the product is suitable for the intended application.
- In reversible underfloor heating and cooling systems, the floor temperature must not drop below the dew point of the surrounding air to prevent condensation. The preventive application of a moisture barrier (Hydroblocker 2K) is recommended.

TECHNICAL APPROVALS AND QUALITY LABELS

- GEV Emicode EC1plus label: very low VOC emissions
- French VOC emission class A+





This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



info@dl-chem.com - www.dl-chem.com

Last Update: 28-10-2025